



Photo 1 (above); Photo 2 (below)

After the tool has been inserted into the block a .375" pilot is inserted into the tool.

